

RUBBERGRIP

Installation Instructions



1

Remove both bolts and separate grips into two pieces.



2

Place grips on either side of the track.



3

Tap lightly on each end with a rubber mallet if needed. Some skid steer models will require a packing plate on the underside lip for spacing. If the grip is too loose, add packer plate.



4

Align bolt holes. Once bolt holes are aligned, put bolts through and tighten using a wrench. Do NOT over tighten. Do NOT use impact tools to tighten bolts.



5

Repeat steps 1-4 for each grip, spacing them 1½ feet /450mm apart around each track. Spacing should be even.

IMPORTANT INFORMATION

- + Do NOT over tighten. Do NOT use impact tools to tighten bolts.
- + After confirming correct placement, perform another fit check after 10 minutes of use.
- + Check periodically to ensure bolts are still tight.

TrackGrip is designed to improve stability, traction and increase safety within the limitations of your machine. We urge caution and take no responsibility for any consequences arising from the fitted machine being operated outside of the manufacturer's safety guidelines or specifications.