

ICEGRIP

Installation Instructions

1

Remove the two bolts and removable end keeper plate and install the TrackGrip onto the track pad.

2

Make sure the fixed end keeper is seated against the edge of the track.

3

The removable end keeper side will be close to the other end of the track.

4

Install the keeper plate using the supplied bolts. The top two pins are used for alignment only. Use a spanner or wrench.

5

The removable head plate and TrackGrip do not need to be flush as long as the bolts are tight.

Install additional TrackGrips every 5th track pad.

IMPORTANT INFORMATION

- + Do NOT over tighten. Do NOT use impact tools to tighten bolts. No more than 94 pounds of torque on bolts.
- + After confirming correct fitment, perform another fit check after 10 minutes of use.
- + Check periodically to ensure bolts are still tight.
- + Ensure correct protective equipment including gloves and safety glasses are used during installation.

TrackGrip is designed to improve stability, traction and increase safety within the limitations of your machine. We urge caution and take no responsibility for any consequences arising from the fitted machine being operated outside of the manufacturer's safety guidelines or specifications.